Originale	Sostituto	Originale	Sostituto
On/Standby	Power	Red / Movie	Red
Sleep	Sleep	Green / Music	Green
CBL/SAT	1	Blue / Game	Blue
DVD	2	Yellow / Pure	Yellow
Blu-ray	3	Info	Info
Game	4	Option	Options
AUX	5	Volume +	Vol +
Media Player	6	Volume -	Vol -
CD	7	Mute	Mute
TV Audio	8	Back	Back
FM	9	Setup	Menu
M-XPort	Guide	Up	Up
AM	Pre Ch	Down	Down
Channel +	Ch +	Right	Right
Channel -	Ch -	Left	Left
Tune +	>>	Enter	Ok
Tune -	<<	Favorite Station	List

Originale	Sostituto	Originale	Sostituto
2 Favorite Station	SOUND DUAL Dual		
3 Favorite Station	AD SUBT Subt		
MultEQ MultEQ	E-MANUAL D.MENU D. Menu		
DYN EQ DYN EQ	REPEAT TEXT Text		
DYN VOL DYN Vol	ZOOM Eject		
M-DAX M-DAX	TIMER AV AV		