







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up / P+	 Up
 Mute	 Mute	 Up / P+	 Ch +
 1	 1	 Audio	 Dual
 02	 2	 Left / Vol-	 Left
 3	 3	 Left / Vol-	 Vol -
 4	 4	 Right / Vol+	 Right
 5	 5	 Right / Vol+	 Vol +
 6	 6	 Down / P-	 Down
 7	 7	 Down / P-	 Ch -
 8	 8	 Text	 Text
 9	 9	 Input	 AV
 i	 Info	 Red	 Red
 0	 0	 Green	 Green
 R	 Back	 Yellow	 Yellow
 □	 Media	 Blue	 Blue
 Sleep	 Sleep	 Text Cancel	 Stop
 ■	 Smart	 Text Reveal	 Play



