





































Originale	Sostituto
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Recall	 Pre Ch
 SS-Titre	 Subt
 Accueil	 D. Menu
 YouTube	 Media

Originale	Sostituto
 Netflix	 Smart
 Reg.Rapide	 3D
 Menu	 Menu
 Retour/Guide	 Guide
 Sortie	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK/Liste	 Ok
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute





Originale		Sostituto	
	CH+		Ch +
	CH-		Ch -
	I/II Audio/Lang		Dual
	Play		Play
	Pause/Index		Pause
	Stop/Garde		Stop
	Rec/Mix		Rec
	I<<		I<<
	Texte		Text
	>>I		>>I
	Taille		Format
	<</Revele		<<
	>>/Annule		>>
	Heure/Pg Ht		List
	SS-Code/Pg Bs		Sleep

Originale		Sostituto	

