












































































































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---------------|---|---------------|---|-------------------|---|---------|
|  | Power On |  | Power |  | I<< |  | I<< |
|  | Power/Standby |  | Shift + Power |  | Play |  | Play |
|  | Sleep |  | Sleep |  | >>I |  | >>I |
|  | Display/DVD |  | Media |  | << |  | << |
|  | OSD Menu |  | Menu |  | Stop |  | Stop |
|  | CH+ |  | Ch + |  | >> |  | >> |
|  | CH- |  | Ch - |  | Rec |  | Rec |
|  | Vol+ |  | Vol + |  | Pause |  | Pause |
|  | Vol- |  | Vol - |  | Eject |  | Eject |
|  | Up |  | Up |  | Input Sel. DVD |  | Options |
|  | Left |  | Left |  | Input Sel. Multi |  | Dual |
|  | Enter |  | Ok |  | Input Sel. CD |  | Text |
|  | Right |  | Right |  | Input Sel. Tun |  | AV |
|  | Down |  | Down |  | Input Sel. Tap |  | Format |
|  | Exit/Return |  | Exit |  | Input Sel. PH |  | 3D |
|  | Test/Tv/VCR |  | TV/R |  | Input Sel. PIP V1 |  | Red |
|  | Muting |  | Mute |  | Input Sel. PIP V2 |  | Green |





| Originale | | Sostituto | | Originale | | Sostituto | |
|---|-------------|---|-------|---|-----|---|--------|
|  | Power |  | Power |  | 1 |  | 1 |
|  | Enter |  | Ok |  | 2 |  | 2 |
|  | Display DVD |  | Media |  | 3 |  | 3 |
|  | Up |  | Up |  | 4 |  | 4 |
|  | OSD Menu |  | Menu |  | 5 |  | 5 |
|  | Down |  | Down |  | 6 |  | 6 |
|  | Exit/Return |  | Exit |  | 7 |  | 7 |
|  | Right |  | Right |  | 8 |  | 8 |
|  | I<< |  | I<< |  | 9 |  | 9 |
|  | Left |  | Left |  | 0 |  | 0 |
|  | Play |  | Play |  | +10 |  | Guide |
|  | >>I |  | >>I |  | Ent |  | Pre Ch |
|  | << |  | << | | | | |
|  | Stop |  | Stop | | | | |
|  | >> |  | >> | | | | |
|  | Pause |  | Pause | | | | |
|  | Eject |  | Eject | | | | |



