



Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Radio/Tv	 TV/R
 Last View	 Pre Ch
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Internet	 Smart
 Guide	 Guide

Originale	Sostituto
 i/Status	 Info
 X/Exit	 Exit
 Option	 Options
 Return	 Back
 Play/x1.3	 Play
 Pause/PAUSE LIVE	 Pause
 STOP	 Stop
 >>	 >>
 <<	 <<
 <</Remind Live	 <<
 >>	 >>
 REC	 Rec
 Function Menu	 Menu
 Direct Navigator/PopUp	 List
 OK	 Ok
 Up	 Up
 Down	 Down



