





































Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Last View	 Pre Ch
 Radio/Tv	 TV/R
 Internet	 Smart
 Netflix	 Media
 Rec	 Rec
 Prog/Check	 Sleep

Originale	Sostituto
 Play	 Play
 >>	 >>
 <<	 <<
 Pause	 Pause
 >>	 >>
 <<	 <<
 Stop	 Stop
 Exit	 Exit
 i/Status	 Info
 Return	 Back
 Guide	 Guide
 Function Menu	 Menu
 Video Menu	 D. Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left



