













Originale	Sostituto	Originale	Sostituto
	Power		Power
	TV Input Selector		TV/Radio /
	BD/DVD Input Selector		Smart / List
	Subwoofer+		Up
	Subwoofer-		Down
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer

