




























































































Originale	Sostituto
 Power	 Power
 Source	 AV
 blank	 TV/R
 [> <]	 Options
 square	 D. Menu
 Red / Rec / Movie	 Red
 Red / Rec / Movie	 Rec
 Green / << /	 Green
 Green / << /	 <<
 Yellow / Stop / Child	 Yellow
 Yellow / Stop / Child	 Stop
 Blue / Play / News	 Blue
 Blue / Play / News	 Play
 >> / Other	 >>
 Guide	 Guide
 Text	 Text
 Up	 Up

Originale	Sostituto
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Menu	 Menu
 V +	 Vol +
 V -	 Vol -
 Mute	 Mute
 P +	 Ch +
 P -	 Ch -
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7







Originale		Sostituto		Originale		Sostituto	
	Power		Power		1		1
	Rec		Rec		2		2
	<<		<<		3		3
	<<		I<<		4		4
	Stop		Stop		5		5
	Play		Play		6		6
	>>		>>		7		7
	>>		>>I		8		8
	Up		Up		9		9
	Down		Down		0		0
	Right		Right		i+		Info
	Left		Left		P < P / -/--		Pre Ch
	OK		Ok		Timer		AV
	Text		Text		[?]		D. Menu
	Menu		Menu		Zoom		Eject
	P +		Ch +		I / II		Dual
	P -		Ch -				

