







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Green		Green / APP / Repeat
	DTV		Shift + TV/Radio / Program		Yellow		Yellow / YouTube / Repeat
	TV		TV/Radio /		Blue		Blue / Prime Video / Random
	AV		AV / Input / RDS		Vol+		Vol+
	1		1		i		Info / Angle
	2		2		CH+		CH+ / Page+
	3		3		Vol-		Vol-
	4		4		Mute		Mute / Dimmer
	5		5		CH-		CH- / Page-
	6		6		EPG		Guide / EPG / -/--
	7		7		Option		Setup / OPT /
	8		8		Up		Up
	9		9		Left		Left
	Text		Text / Goto		OK		OK
	0		0		Right		Right
	PRE-CH		Back / Return		Down		Down
	Red		Red / Netflix / Search		Menu		Menu / Home





Originale		Sostituto	
	Exit		Exit / Cancel / Clear
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	Rec		Rec / Rec Mode
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	File List/[≡i]		Smart / List
	Bookmark/[.≡]		Display / Media
	Repeat/[≡O]		Shift + Green / APP / REPEAT
	A<>B/[≡?]		Shift + Yellow / YouTube / REPEAT A-B
	PIC Size		Zoom / Size
	PIC Mode		Picture / Format
	SND Mode		Sleep / Timer
	M/S		D.Menu / Top

Originale		Sostituto	

