



Originale	Sostituto
 Standby	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 F.List	 Media
 RES	 Smart
 Repeat	 Text
 Capture	 Format
 Book.M	 3D

Originale	Sostituto
 Book.J	 Shift + 3D
 R.Skip	 I<<
 REW	 <<
 FWD	 >>
 F.Skip	 >>I
 Rec	 Rec
 Stop	 Stop
 Play	 Play
 Pause	 Pause
 Menu	 Menu
 Exit	 Exit
 Info	 Info
 Back	 Back
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right





Originale	Sostituto
	Down
	Vol +
	Vol -
	Ch +
	Ch -
	Red
	Dual
	Green
	Subt
	Yellow
	Shift + Text
	Blue
	Sleep
	Guide
	Pre Ch
	List
	Eject

Originale	Sostituto
	Options
	Shift + Options
	TV/R
	AV

