




Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Audio	 Dual
 TV / STB	 Shift + TV/R
 TV / R	 TV/R
 Sleep	 Sleep
 SUB	 Subt
 TXT	 Text
 P / N	 Shift + 1
 Recall	 Pre Ch
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7

Originale	Sostituto
 8	 8
 9	 9
 0	 0
 PGUP	 Vol +
 PGDN	 Vol -
 SAT	 Shift + AV
 FAV +	 Ch +
 FAV -	 Ch -
 EPG	 Guide
 Fav	 Shift + Pre Ch
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 Menu	 Menu
 Exit	 Exit



