







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 PR+	 Ch +
 Source	 AV	 PR-	 Ch -
 1	 1	 CH List	 List
 2	 2	 Content	 Smart
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Info	 Info
 6	 6	 Tools	 Options
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 TTX/MIX	 Text	 Enter	 Ok
 PRE-CH	 Pre Ch	 Return	 Back
 Vol+	 Vol +	 Exit	 Exit
 Vol-	 Vol -	 Red/A	 Red
 Mute	 Mute	 Green/B	 Green

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 PR+	 Ch +
 Source	 AV	 PR-	 Ch -
 1	 1	 CH List	 List
 2	 2	 Content	 Smart
 3	 3	 Menu	 Menu
 4	 4	 Guide	 Guide
 5	 5	 Info	 Info
 6	 6	 Tools	 Options
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 TTX/MIX	 Text	 Enter	 Ok
 PRE-CH	 Pre Ch	 Return	 Back
 Vol+	 Vol +	 Exit	 Exit
 Vol-	 Vol -	 Red/A	 Red
 Mute	 Mute	 Green/B	 Green





Originale	Sostituto
Yellow/C	Yellow
Blue/D	Blue
Internet TV	TV/R
Media.P	Media
Dual I-II	Dual
AD	+ Shift + Subt
P.Size	Format
Subt.	Subt
<<	<<
Pause	Pause
>>	>>
Rec	Rec
Play	Play
Stop	Stop

Originale	Sostituto

