





































Originale	Sostituto
 Power	 Power
 Input+	 Ch +
 Input-	 Ch -
 Clear Audio+	 Exit
 Display	 Info
 Voice	 Sleep
 Night	 Media
 Bluetooth/Pairing	 TV/R
 Music Service	 Subt
 Dimmer	 Pre Ch
 Options	 Options
 Back	 Back
 Home	 Smart
 Mute	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up

Originale	Sostituto
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 SW Vol+	 Shift + Vol +
 SW Vol-	 Shift + Vol -
 Play	 Play
 <<<	 <<<
 >>>	 >>>
	 Pause
 <<	 <<
 >>	 >>
 ■	 Stop
 Sound Field	 3D
 Audio	 Dual
 Bluetooth RX/TX	 Text
 Red	 Red





Originale		Sostituto		Originale		Sostituto	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				

