











































	Originale	Sostituto
	Power	 Power
	Open/Close	 Eject
	1	 1
	2	 2
	3	 3
	4	 4
	5	 5
	6	 6
	7	 7
	8	 8
	9	 9
	0	 0
	Alarm1	 Red
	Alarm2	 Blue
	Clock	 +  Shift + AV
	Sleep	 Sleep
	Display	 Info

	Originale	Sostituto
	Audio	 Dual
	Source	 AV
	Mute Snooze	 Mute
	Vol+	 Vol +
	Vol-	 Vol -
	Up	 Up
	Down	 Down
	Right	 Right
	Left	 Left
	Enter	 Ok
	>> /Tu+	 >>
	<</Tu-	  <<
	Stop	 Stop
	Play	 Play
	Pause	 Pause
	Repeat	 Text
	Shuff	 Media





	Originale	Sostituto
	Intro	 Guide
	Folder+	 Ch +
	Folder-	 Ch -

	Originale	Sostituto

