




























































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P+	 CH+ / Page+
 1	 1	 V-	 Vol-
 2	 2	 Source	 AV / Input / RDS
 3	 3	 P-	 CH- / Page-
 4	 4	 [G]	 Guide / EPG / -/-
 5	 5	 i	 Info / Angle
 6	 6	 Up	 Up
 7	 7	 Left	 Left
 8	 8	 OK	 OK
 9	 9	 Right	 Right
 Lang	 Audio / Lang I/II	 ←	 Back / Return
 0	 0	 Down	 Down
 [≡]...	 Subtitle / EQ	 Exit	 Exit / Cancel / Clear
 Home	 Shift + Menu /	 Netflix	 Shift + Red / Netflix /
 Home	 D.Menu / Top	 YouTube	 Shift + Yellow / YouTube /
 V+	 Vol+	 Menu	 Menu / Home
 Mute	 Mute / Dimmer	 *1	 Picture / Format





Originale	Sostituto
 <<	 << / Tune-
 Stop	 Stop / Hold
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Text	 Text / Goto
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random

Originale	Sostituto

