

























Originale	Sostituto	Originale	Sostituto
 Power	 Power	 2	 2
 Red/Setup	 Red	 3	 3
 Green/APP	 Green	 4	 4
 Yellow	 Yellow	 5	 5
 Blue	 Blue	 6	 6
 Vol+	 Vol +	 7	 7
 Vol-	 Vol -	 8	 8
 Home	 Smart	 9	 9
 Back	 Back	 0	 0
 I=I	 Menu	 Mute	 Mute
 Mouse	 Media	 <XI	 Pre Ch
 Up	 Up		
 Down	 Down		
 Right	 Right		
 Left	 Left		
 OK	 Ok		
 1	 1		

Originale	Sostituto	Originale	Sostituto
 2	 2		
 3	 3		
 4	 4		
 5	 5		
 6	 6		
 7	 7		
 8	 8		
 9	 9		
 0	 0		
 Mute	 Mute		
 <XI	 Pre Ch		

