

































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Down/CH-		Down
	Mute		Mute		Right		Right
	1		1		Left		Left
	2		2		OK		Ok
	3		3		Vol+		Vol +
	4		4		Vol-		Vol -
	5		5		Menu		Menu
	6		6		Exit		Exit
	7		7		Red		Red
	8		8		Green		Green
	9		9		Yellow		Yellow
	0		0		Blue		Blue
	PgUp		Ch +		EPG		Guide
	PgDn		Ch -		Audio		Dual
	FAV+		>>I		SUB		Subt
	FAV-		I<<		Zoom		Eject
	Up/CH+		Up		FAV		Pre Ch





Originale		Sostituto		Originale		Sostituto
	List		List			
	Pause		Pause			
	TXT		Text			
	Info		Info			
	Tv/Radio		TV/R			
	Recall		Back			

