






































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 ZAP	 Pre Ch
 Source	 AV	 Format	 Format
 TV	 TV/R	 Mute	 Mute
 VIDEO	 Smart	 PIP	 3D
 PC	 Media	 Text	 Text
 1	 1	 Up / P+	 Up
 2	 2	 Up / P+	 Ch +
 3	 3	 Down / P-	 Down
 4	 4	 Down / P-	 Ch -
 5	 5	 Right / Vol+	 Right
 6	 6	 Right / Vol+	 Vol +
 7	 7	 Left / Vol-	 Left
 8	 8	 Left / Vol-	 Vol -
 9	 9	 Menu	 Menu
 0	 0	 PIP Swap	 Back
 i	 Info	 Auto	 Options
 List	 List	 Sound	 Dual

Originale	Sostituto	Originale	Sostituto
 ZAP	 Pre Ch	 Format	 Format
 Mute	 Mute	 PIP	 3D
 Text	 Text	 Up / P+	 Up
 Up / P+	 Ch +	 Down / P-	 Down
 Down / P-	 Ch -	 Right / Vol+	 Right
 Right / Vol+	 Vol +	 Left / Vol-	 Left
 Left / Vol-	 Vol -	 Menu	 Menu
 PIP Swap	 Back	 Auto	 Options
 Sound	 Dual		





Originale	Sostituto
Freeze / Hold	+  Shift + Stop
<<	<<
Play	Play
>>	>>
Rec	Rec
Stop	Stop
Pause	Pause
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
F1	+  Shift + 1
F2	+  Shift + 2
F3	+  Shift + 3
F4	+  Shift + 4
P-Pos	+  Shift + Ch +
P-Size	+  Shift + Ch -

Originale	Sostituto
Clock / Mix	+  Shift + Text

