














































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 ATV/DTV	 D. Menu
 Recall	 Back
 P.Mode	 Format
 S.Mode	 Dual
 Sleep	 Sleep

Originale	Sostituto
 MTS	 Media
 Menu	 Menu
 Source	 AV
 Exit	 Exit
 Display	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Rec	 Rec
 Rec List	 List
 Tv/Radio	 TV/R
 FAV List	 Pre Ch
 CH+	 Ch +





Originale		Sostituto		Originale		Sostituto	
	CH-		Ch -		Cyan		Blue
	Play		Play				
	Pause/Time Shift		Pause				
	<</Guide		<<				
	>>/Aspect		>>				
	Stop/Index		Stop				
	I<</Cancel		I<<				
	>>I/Sub.PG		>>I				
	Freeze		Eject				
	Subtitle		Subt				
	Size		3D				
	Reveal		Options				
	Hold		Smart				
	Text		Text				
	Red		Red				
	Green		Green				
	Yellow		Yellow				

