Mandis shop

Samsung DJ 96-00191B

Original		Replacement	
	Power		Power
Auto	Auto	5 AUDIO	5 / Audio
	Home	GOTO	Eject / GOTO
Spot	Spot	1 SETUP	1 / Setup
Max	Max	2 MENU	2 / Menu
Manual	Manual	3 EXIT	3 / Exit
	Up		Up
	Right		Right
	Left		Left
	Play/Pause	BAND	Play / Band
Silence	Silence	7 REP	7 / Rep
Dust Sensor	Dust Sensor	8 A-B	8 / A-B
Sound	Sound	9 DISP	9 / Disp
Schedule Cancel (3sec)	Schedule/Cancel (3 Sec)	-- SEAR	-- / Sear
Clock	Clock	0 ZOOM	0 / Zoom
Remote	Remote	IIANG	IIAng

Original	Replacement

https://remotecontrols.com/Samsung/1557-552-replacement-remote-control-for-Samsung-DJ96-00191B.htm