Mandis shop

Sony RMT-CDS11IP

Original	Replacement
Off	Power
Mode	Format
Radio/Band	TV/R
Audio In	AV
I<</Tune-	I<<
Play	Play
Pause	Pause
>>I/Tune+	>>I
Preset+	Ch +
Preset-	Ch -
Up	Up
Down	Down
Vol+	Vol +
Vol-	Vol -
Menu	Menu
Enter	Ok
Mega Bass	Smart

Original	Replacement
Mega Xpand	Media
Snooze	Mute

https://remote-controls.ch/en/Sony/1061121-90796-replacement-remote-control-for-Sony-RMT-CDS11IP-988514353.html