Mandis shop

JVC RM-MH18G

Original	Replacement
Standby	SHIFT + Power
On	Power
HDMI 1	1
HDMI 2	2
COMP	4
3D Format	Picture / Format
3D Setting	Setup / OPT /
PC	Fav / Marker / PC
Lens Control	Guide / EPG / -/--
Lens Memory	0
C.M.D.	6
Hide	9
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down

Original	Replacement
Menu	Menu / Home
Back	Back / Return
Film	Green / APP / Repeat
Cinema	Yellow / YouTube / Repeat
Anime.	Red / Netflix / Search
Natural	7
Stage	8
3D	Zoom / Size
THX	Text / Goto
User	Info / Angle
MPC	5
Gamma	Blue / Prime Video / Random
Color Temp	Display / Media
Color P.File	Smart / List
Pic. Adj.	D.Menu / Top

https://remotecontrols.com/JVC-RM-MH18G-replacement-remote-control-for-JVC-RM-MH18G-P23359.htm