Original	Replacement
Power	Power
TV Set Power	Shift + Power
TV Set V +	Vol +
TV Set V -	Vol -
Mute	Mute
TV Mode	Options
TV / Rad	TV/R
Find	Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9

Original	Replacement
0	0
Recall	Back
Audio	Dual
Menu	Menu
Exit	Exit
Up	Up
Right	Right
Down	Down
Left	Left
OK	Ok
Sat	AV
Fav	Pre Ch
PG +	Ch +
PG -	Ch -
YouTube	Smart
Play / Pauln fo	Info
EPG	Guide

Original	Replacement	Original	Replacement
Play / Pause	PLAY MODE ▶ Play		
Play / Pause	❚❚ Pause		
<< FB	<<		
>> FF	>>		
Stop	■ Stop		
I << Prev	I <<		
>>I Next	>>I		
Sleep	PROG SLEEP Sleep		
Sub-T	AD SUBT Subt		
Text	REPEAT TEXT Text		
Rec	REC MODE ● Rec		
Red / IPTV	A Red		
Green / Video	B Green		
Yellow / PVR	C Yellow		
Blue / Timer	D Blue		

Original	Replacement	Original	Replacement
Power	Power	Text	Text
Mute	Mute	PG+	Ch +
Menu	Menu	PG-	Ch -
Exit	Exit	Up	Up
1	1	Left	Left
2	2	OK	Ok
3	3	Right	Right
4	4	Down	Down
5	5	Recall	Back
6	6	Sleep	Sleep
7	7	Find	Shift + TV/R
8	8	TV / Rad	TV/R
9	9	Info	Info
0	0	EPG	Guide
SAT	AV	FAV	Pre Ch
TV Mode	Smart	YouTube	Media
S. Mode	Shift + Dual	Red / M/P	Red

Original	Replacement	Original	Replacement
Green / Video	B Green		
Yellow / PVR	C Yellow		
Blue / Timer	D Blue		
Audio	SOUND DUAL Dual		
Subtitle	AD SUBT Subt		
Stop	■ Stop		
Rec	REC MODE ● Rec		
Play/Pause	PLAY MODE ▶ Play		
Play/Pause	❚❚ Pause		