# Mandis shop

Echostar 005




| Original | | Replacement | |
|---|---|---|---|
| | Standby | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | SAT / Recall | | Smart |
| | SAT / Recall | | Back |
| | Favorite | | Pre Ch |
| | View | | Info |
| | Cancel | | Exit |
| | Up / Channel + | | Up |

| Original | | Replacement | |
|---|---|---|---|
| | Up / Channel + | | Ch + |
| | Down / | | Down |
| | Down / | | Ch - |
| | Right | | Right |
| | Left | | Left |
| | Select | | Ok |
| | Mute | | Mute |
| | Vol + | | Vol + |
| | Vol - | | Vol - |
| | Menu | | Menu |
| | A/V | | AV |
| | Tune | | Media |
| | Text | | Text |
| | Subtitle | | Subt |
| | Store | | Options |
| | Reveal | | 3D |
| | Aspect | | Format |

https://remotes.com/replacement-remote-for-Echostar005.htm