Mandis shop

MORE001

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| ON/OFF | On/Off | | Power | | |
| TIMING | Timing | TIMER SLEEP | Sleep / Timer | | |
| NIGHT LIGHT | Night Light | CLEAR EXIT CANCEL | Exit / Cancel / Clear | | |
| MUSIC | Music | LANG I/II AUDIO | Audio / Lang I/II | | |
| COLOR LIGHT | Color Light | RETURN BACK | Back / Return | | |
| ROTATION | Rotation | MEDIA DISPLAY | Display / Media | | |

https://remote-controls.ch/en/Moredig/1066444-96449-replacement-remote-control-for-Moredig-MORE001.html