Mandis shop

BOM003

Original	Replacement	Original	Replacement
Program	TV/ Radio /		
- 10/ Fol -	CH- / Page-		
+10/ Fol +	CH+ / Page+		
Play USB	Play / Slow		
Pause USB	Pause / Step / Freeze		
I <<	I << / Preset -		
<<	<< / Tune-		
>>	>> / Tune+		
>>I	>>I / Preset +		
Stop	Stop / Hold		
Repeat / Random	Green / APP / Repeat		
Vol -	Vol -		
Vol +	Vol +		

https://remotecontrols.com/BOM003-replacement-remote-control-for-BOM003.html