Mandis shop

Philips CRP763-01

Original		Replacement		Original	Replacement
POWER	Power		Power		
▶/II	Play	SLOW ▶	Play / Slow		
▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
TURBO	Turbo	LIST SMART	Smart / List		
BASE	Base	MEDIA DISPLAY	Display / Media		
CLOCK	Clock	PROGRAM TV/RADIO	TV/Radio /		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
TIME	Time-	CH PAGE −	CH- / Page-		
TIME	Time+	+ CH PAGE	CH+ / Page+		
MODE	Mode	FORMAT PICTURE	Picture / Format		
	Up		Up		
	Left		Left		
ENTER	Enter	OK	OK		
	Right		Right		
	Down		Down		

https://remotecontrol.com/Philips/10729-524-replacement-remote-control-for-Philips-CRP763-01-22594361.htm