Mandis shop

Sony RMT-AH411U

Original	Replacement	Original	Replacement
Input	AV / Input / RDS	Play	Play / Slow
Power	Power	Pause	Pause / Step / Freeze
Auto Sound	Sound / Title	I <<	I << / Preset-
Standard	Zoom / Size	>>I	>>I / Preset+
Cinema	Picture / Format		
Music	TV/Radio /		
Voice	Display / Media		
Night	Exit / Cancel / Clear		
Vol +	Vol +		
Vol -	Vol -		
Indicator	Info / Angle		
Mute	Mute / Dimmer		
Play Mode	Red / Netflix / Search		
Audio	Audio / Lang I/II		
Up	Up		
Enter	OK		
Down	Down		

https://remote-controls.de/en/Sony/10679-9257-replacement-remote-control-for-Sony-RMT-AH411U-143601.htm