Mandis shop

BRAUN001

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | | |
| Up | Up | | |
| Down | Down | | |
| Left | Left | | |
| Right | Right | | |
| Enter | Enter | | |
| Setup | Menu | | |
| Exit | Shift + Power | | |
| Rotate | Eco / Aspect | | |
| Zoom | - / Stop | | |
| Slide Show | Freeze / Timer | | |

https://remote-controls.ch/en/Braun/1065506-79592-replacement-remote-control-for-Braun-Braun001.html