Original	Replacement	Original	Replacement
On/Off	Power	OK Enter	Ok
Mute	Mute	Menu Right	Right
Update	Play	Menu Off	Exit
Reveal	Pause	Menu Down	Down
Txt Stop	Stop	Back	Back
Info	Info	Volume+	Vol +
Subt. List	Subt	Chan. Up	Ch +
Sleep Timer	Sleep	Volume-	Vol -
Return TV	TV/R	Menu audio	Dual
Menu video	D. Menu	Chan. Down	Ch -
Text	Text	1	1
Txt Expand	Eject	2	2
TV/AV	AV	3	3
Menu	Menu	4	4
Menu Up	Up	5	5
Display	Shift + Info	6	6
Menu Left	Left	7	7

Original	Replacement
8	8
9	9
Guide -/-- 1.	GUIDE
0/10	0
2. Fav P/C 2.	FAV PRE-CH
Red	A
Green	B
Yellow	C
Blue	D
Tone+	ECO 3D
Off/Tim	SHIFT + PROG SLEEP
Mix Scan	PICTURE FORMAT
Game Coo	SHIFT + ZOOM
Disp	DISC NAV LIST
Search	SHIFT + SEARCH TV/R
Tune-	<<
Aft/Caf	SHIFT + OK

Original	Replacement
Store	APP MEDIA
Browse	HOME SMART
Tune+	>>

Original	Replacement	Original	Replacement
On/Off	Power	OK Enter	Ok
Mute	Mute	Menu Right	Right
Update	Play	Menu Off	Exit
Reveal	Pause	Menu Down	Down
Txt Stop	Stop	Back	Back
Info	Info	Volume+	Vol +
Subt. List	Subt	Chan. Up	Ch +
Sleep Timer	Sleep	Volume-	Vol -
Return TV	TV/R	Menu audio	Dual
Menu video	D. Menu	Chan. Down	Ch -
Text	Text	1	1
Txt Expand	Eject	2	2
TV/AV	AV	3	3
Menu	Menu	4	4
Menu Up	Up	5	5
Display	Shift + Info	6	6
Menu Left	Left	7	7

Original	Replacement
8	8
9	9
Guide -/-- 1.	Guide
0/10	0
2. Fav P/C 2.	Pre Ch
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
On/Off	Shift + Power
Rotate Text	Shift + Mute
Tone+	3D
On/Tim	Shift + Subt
Off/Tim	Shift + Sleep
Mix Scan	Shift + TV/R
Color+ P.Std	Shift + Format
Store Text	Shift + Text

Original	Replacement
AV 2	Shift + AV
Bright+ Mode	Shift + Menu
Search	Shift + Up
Tune-	Shift + Left
Disp	List
Tune+	Shift + Right
Bright- Sys	Shift + Exit
Store	Shift + Down
Input	Shift + Vol +
Contrast+	Shift + Ch +
Output	Shift + Vol -
Contrast-	Shift + Ch -
Color- S.Std	Shift + Dual
On Pip	Shift + 1
Swap	Shift + 2
Rotate Pip	Shift + 3
Still	Shift + 4

Original	Replacement	Original	Replacement
Dim Pip	SHIFT + 5 Shift + 5		
Help	SHIFT + 6 Shift + 6		
Camera	SHIFT + 7 Shift + 7		
Camera1	SHIFT + 8 Shift + 8		
3. *	SHIFT + GUIDE Shift + Guide		
View	SHIFT + 0 Shift + 0		
4. # 16: 9	PICTURE FORMAT Format		