| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| 0 | 0 | HDMI - SAT 0 | 0 |
| TXT | TXT | GOTO TEXT | Text / Goto |
| | Red | NETFLIX SEARCH | Red / Netflix / Search |
| | Green | APP REPEAT | Green / APP / Repeat |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random |

| Original | | Replacement | |
|---|---|---|---|
| CEC | CEC | LIST SMART | Smart / List |
| ? | ? | TOP MENU D.MENU | D. Menu / Top |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| MENU | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| BACK | Back | RETURN BACK | Back / Return |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| GUIDE | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- |
| TOOLS | Tools | OPT-TOOLS SETUP | Setup / OPT / |
| | Vol + | VOL + | Vol + |
| | Source | RDS AV INPUT | AV / Input / RDS |
| P | PR+ | CH PAGE + | CH+ / Page+ |
| | Vol - | VOL − | Vol - |
| | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| P – | PR- | CH PAGE – | CH- / Page- | | |
| ⏮ | I < | PRESET- ⏮ | I << / Preset- | | |
| ⏭ | >I | PRESET+ ⏭ | >>I / Preset+ | | |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- | | |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ | | |
| ● | Rec | REC MODE ● | Rec / Rec Mode | | |
| ▶ | Play | SLOW ▶ | Play / Slow | | |
| ❚❚ | Pause | STEP-FREEZE ❚❚ | Pause / Step / Freeze | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | |
| [<>] | [<>] | FORMAT PICTURE | Picture / Format | | |
| | Dialog | LANG I/II AUDIO | Audio / Lang I/II | | |
| [...] | [...] | EQ SUBTITLE | Subtitle / EQ | | |
| TV/Radio | Tv/Radio | PROGRAM TV/ RADIO | TV/Radio / | | |
| My Media | My Media | MEDIA DISPLAY | Display / Media | | |
| | | | | | |
| | | | | | |
| | | | | | |