Mandis shop

Philips 996510067904

Original		Replacement	
	Power		Power
HDMI ARC	HDMI ARC	HDMI - SAT 0	0
Bluetooth	Bluetooth	BLUETOOTH 9	9
AUX/ AUDIO IN	AUX/ Audio In	AUX - HDD 7	7
USB	USB	USB 8	8
COAX/ OPTICAL	Coax/ Optical	TUNER 6	6
	I<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze
	>I	PRESET+	>>I / Preset+
+ BASS	Bass+		Right
+ VOLUME	Vol +	+ VOL	Vol +
+ TREBLE	Treble+		Up
BASS –	Bass-		Left
VOLUME –	Vol -	VOL –	Vol -
TREBLE –	Treble-		Down
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Replacement	
SOUND	Sound	TITLE SOUND	Sound / Title
SURR	Surr	SURROUND	Eject / Surround
DIM	DIM	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
NIGHT MODE	Night Mode	TIMER SLEEP	Sleep / Timer

https://remotecontrol.com/Philips/1556-728-replacement-remote-control-for-Philips-Soundstage-996510067904.htm