Mandis shop

Aeg BSS 4806

Original		Rechange	
STANDBY	Standby		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
▶II	Play / Pause	STEP-FREEZE II	Pause / Step / Freeze
▶II	Play / Pause	SLOW ▶	Play / Slow
AUX	AUX	AUX - HDD 7	7
Bluetooth LINE	Line / Bluetooth	BLUETOOTH 9	9
SEARCH+	>> / Search+	TUNE+ ▶▶	>> / Tune+
RADIO-	I<< / Radio-	PRESET- ⏮	I<< / Preset-
■	Stop	HOLD ■	Stop / Hold
RADIO+	>>I / Radio+	PRESET+ ⏭	>>I / Preset+
MEMORY REPEAT	Repeat /	APP REPEAT	Green / APP / Repeat
SEARCH-	<< / Search-	TUNE- ◀◀	<< / Tune-
TUNER USB	USB / Tuner	TUNER 6	6
VOL-	Vol-	VOL −	Vol-
CH-LEVEL	CH. Level	LIST SMART	Smart / List
VOL+	Vol+	+ VOL	Vol+
LOUDNE	Loudne	TITLE SOUND	Sound / Title

Original		Rechange	
EQ	EQ	EQ SUBTITLE	Subtitle / EQ
MO/ST	Mo / St	LANG I/II AUDIO	Audio / Lang I/II
SCAN	Scan	MEDIA DISPLAY	Display / Media

https://remote-controls.ch/fr/Aeg/1061617-91088-telecommande-de-remplacement-pour-Aeg-BSS-4806-BBS4806.html