Mandis shop

RB- DA1200M

Original		Rechange	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
⏻/ON	Power / On		Power
FUNCTION	Function	HOME MENU	Menu / Home
MEMORY	Memory	LIST SMART	Smart / List
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PRESET FOLDER SELECT	Preset / Folder Select	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
OVER	Over	PC FAV MARKER	Fav / Marker / PC

Original		Rechange	
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
VOL −	Vol -	VOL −	Vol -
SOUND	Sound	TITLE SOUND	Sound / Title
VOL +	Vol +	+ VOL	Vol +
■	Stop	HOLD ■	Stop / Hold
TUNING	I<< / Tuning / File-	PRESET- ⏮	I<< / Preset-
TUNING/FILE +	>>I / Tuning / File+	PRESET+ ⏭	>>I / Preset+
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TUNER/BAND	Tuner / Band	PROGRAM TV/ RADIO	TV/ Radio /
FM MODE REPEAT	FM	APP REPEAT	Green / APP / Repeat

https://remotecontrols.fr/Sanyo/10756596-telecommande-de-remplacement-pour-Sanyo-RB-DA1200M.htm