Mandis shop

Samsung AH5902710A

Originale		Sostituto	
POWER	Power		Power
MUTE	Mute	MUTE	Mute
AUX	AUX	APP MEDIA	Media
D.IN	D.IN	HOME SMART	Smart
WOOFER LEVEL	Woofer Level	CH +	Ch +
WOOFER LEVEL	Woofer Level	CH −	Ch -
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
>>I	>>I	>>I	>>I
I<<	I<<	I<<	I<<
TV SOUND CONNECT	Tv Sound	SEARCH TV/R	TV/R
Bluetooth	Bluetooth	SETTINGS OPT	Options
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
AUTO POWER	Auto Power	PROG SLEEP	Sleep
Bluetooth POWER	Bluetooth	SHIFT + Power	Shift + Power

Originale		Sostituto	
USB	USB	TIMER AV	AV