Originale		Sostituto	
POWER	Power		Power
FUNCTION TV SOURCE	Function	TIMER AV	AV
	Eject	ZOOM	Eject
SLEEP	Sleep	PROG SLEEP	Sleep
RDS DISPLAY 1	1 / RDS Displa	1	1
2	2	2	2
TA 3	3 / TA	3	3
PTY- 4	4 / PTY -	4	4
PTY SEARCH 5	5 / PTY Search	5	5
PTY+ 6	6 / PTY +	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FULL SCREEN	Full Screen	SHIFT + ZOOM	Shift + Eject
REPEAT	Repeat	REPEAT TEXT	Text
	I<<		I<<

Originale		Sostituto	
	>>I		>>I
	<<		<<
	>>		>>
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
+ VOL	Vol +	+ VOL	Vol +
VOL —	Vol -	VOL —	Vol -
MUTE	Mute	MUTE	Mute
SFE MODE	SFE Mode	APP MEDIA	Media
TUNING / CH	Tuning / CH +	+ CH	Ch +
TUNING / CH	Tuning / CH -	CH —	Ch -
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
MENU	Menu	TOP MENU MENU	Menu
TITLE MENU POPUP	Title Menu / PopUp Menu	SHIFT + TOP MENU MENU	Shift + Menu
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info

Originale		Sostituto	
	Up		Up
	Left		Left
	Enter	OK	Ok
	Right		Right
	Down		Down
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
A	Red	A	Red
iPod SYNC B	Green / iPod Syn	B	Green
TUNER MEMORY C	Yellow / Tuner Memory	C	Yellow
MO/ST D	Blue / Mb/St	D	Blue
SMART HUB	Smart Hub	HOME SMART	Smart
SEARCH	Search	SHIFT + SEARCH TV/R	Shift + TV/R
vTuner	vTuner	SEARCH TV/R	TV/R
2D→3D	2D → 3D	PICTURE FORMAT	Format
3D SOUND	3D Sound	ECO 3D	3D
DDPLII	Dolby PL II	SHIFT + SOUND DUAL	Shift + Dual

Originale		Sostituto	
DSP	DSP	SOUND DUAL	Dual

Originale		Sostituto	
POWER	Power		Power
FUNCTION TV SOURCE	TV Source	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
RDS DISPLAY 1	1	1	1
2	2	2	2
TA 3	3	3	3
PTY- 4	4	4	4
PTY SEARCH 5	5	5	5
PTY+ 6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
I <<		I <<	
>>I		>>I	
<<		<<	
>>		>>	

Originale		Sostituto	
	Stop		Stop
	Play	PLAY MODE	Play
	Pause		Pause
+ VOL	Vol +	+ VOL	Vol +
VOL —	Vol -	VOL —	Vol -
MUTE	Mute	MUTE	Mute
TUNING / CH	CH+	+ CH	Ch +
TUNING / CH	CH-	CH —	Ch -
MENU	Menu	TOP MENU MENU	Menu
TOOLS	Tools	SETTINGS OPT	Options
INFO i	Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Originale		Sostituto		Originale	Sostituto
	Enter	OK	Ok		
A	Red	A	Red		
iPod SYNC B	Green/iPod	B	Green		
TUNER MEMORY C	Yellow/Tuner	C	Yellow		
MO/ST D	Blue/Mo/St	D	Blue		
	HUB/Smart	HOME SMART	Smart		
SEARCH	Search	SEARCH TV/R	TV/R		
2D-3D	2D-3D	ECO 3D	3D		