Mandis shop

REMCON1503



Originale	Sostituto	Originale	Sostituto
Stop	Stop / Hold		
Play	Play / Slow		
</Prev	<< / Tune-		
>/Next	>> / Tune+		
Volume-	Vol-		
Volume+	Vol+		

https://remote-controls.ch/it/UNKNOWN/1066105-84922-telecomando-di-sostituzione-per-UNKNOWN-REMCON1503.html